

## How to Modify/Setup the Display on a Prominent DCM5 Controller

### Step 1: Access the Display Setup Menu

1. Press the MENU button on the controller.
2. Use the **Up/Down** Arrows to navigate to System, then press **OK**.
3. Scroll down to **Display Setup**, then press **OK**.



### Step 2: Select I/O Points for Display

Ensure that Scrolling Display is **NOT** enabled

- If scrolling is enabled, **press F2** (SWITCH) to disable it.
1. **Press F3** (NEXT) to proceed to the next configuration step.
  2. **Press F2** (ADJUST) to modify the I/O points displayed on the home screen.
  3. Use the Up/Down Arrows to locate an I/O point for the top-left corner of the display.
  4. **Press F1** (SELECT) to confirm the selection.
  5. **Press F2** (NEXT) to choose the next I/O point.
  6. Repeat this process for all display slots as needed.
    - If setting up a dual body controller, you will set up the first body of water on the left (Usually CL/ORP, pH, and Temperature are set, but any can sensor can be displayed) and the second body of water on the right.



### Step 3: Finalize and Save Settings

1. Once all I/O points are selected, the changes will be applied.
2. At any time, you can press the **ESC** key to exit without saving.

**For further assistance, call Support at (888)-702-8486**